

Instructions

Part # TF9051. Each kit will be enough to patch multiple areas if required. It is recommended to patch areas no larger than 2"x2".



Before



After



Kit Includes:

- Sand
- Cement
- Bonding agent
- Sealer
- Pigment (mixed with cement when required)

Instructions on following page

Patch

1/18

Instructions



1: Remove all loose debris from damaged area. Apply bonding agent with foam brush to area to be patched.



2: Mix sand and cement together. Mix two parts sand to one part cement. Add remainder of bonding agent and mix.



3: Slowly add water to the mix while stirring. The mix should slowly fall from the mixing stick when lifted from container similar to cake batter. Allow to set for 5 minutes.



4: Place the mixture on the damaged area. Press mixture in patch area, making sure not to leave any gaps or holes.



5: Use dry paper towel to press and shape the material to match profile of the product. Remove any extra material.



6: Using a damp sponge, lightly rub the patch to expose the sand. Repeat until it matches the finish of the original product. Use the sponge to remove any extra patch material that isn't required.



7: Place damp paper towel over patched area and let it sit over night to cure.

8. Apply seal that was provided once the patch has dried. +/- 8 hours.